

M  
L E V E L 0



SKYWRITE

VERSA STYLUS PEN


MODEL : LVSTPNBK - LVSTPNWH

# Stylus pen

Replace the tip




Magnetically attach to iPad Pro to turn on, charge and store



Please keep the Bluetooth connection when using the stylus pen ,otherwise the stylus pen will shutdown automatically .


When the stylus pen can't be waked up by your iPad  
Please use this charging pad to wake it up



Wireless charging pad

When you touch the pen with your hand, turn it on.

When the pen leaves your hand, it will automatically turn off after about 2 minutes



The position touched by hand  
can immediately turn on the machine

## Specifications

Physical Size	166mm x 8.9mm* 8.5mm
Weight	15.5g+2g
Nib size	5mm
Battery type	Li-polymer battery
Battery capacity	70mAh
Working Time	10 hours≈
Charging Time	90min≈
Temperature	-10°C ~ + 35°C

- The actual operating time may vary depending on the usage scenarios and other factors.

## Safety information:

- Please avoid rain or damp equipment and accessories, otherwise it may cause fire or electric shock hazard
- Do not place equipment and accessories in areas that are too high or too low in temperature, otherwise it may cause equipment failure, fire or explosion, when the ambient temperature is too high or too low, it may cause equipment failure.
- Do not disassemble, impact, squeeze or modify the battery. It is forbidden to insert foreign objects and puncture the battery. It is forbidden to immerse the battery in water or other liquids to avoid short circuit and overheating, leakage, fire or explosion inside the battery
- Do not disassemble or modify the device (including replacement of the built-in battery) and accessories without authorization, otherwise the device and accessories will not be covered by the company's warranty. Please contact the customer service center if the device fails
- Do not allow children or pets to swallow the battery to avoid injury or explosion of the battery
- Do not use harsh chemicals, cleaning agents, or strong detergents to clean the equipment or accessories. Please use a clean, dry soft cloth to wipe the device or its accessories

## **Package instruction:**

- Smart stylus\*1
- Tip replacement \*2
- Product QR Code
- Charging Cable

## **Environmental protection:**

- Do not dispose of this device and its accessories as household garbage.
- Please comply with the local laws and regulations for the disposal of this equipment and its accessories, and support the recycling operations.
- The battery complies with the environmental protection requirements of the EU RoHS directive.

## **More about:**

This guide is for reference only and does not constitute any form of commitment, products (including but not limited to color, size, screen display, etc.) Please refer to the actual product. If there is any inconsistency between this guide and the description on the official website, please refer to the description on the official website. Without notice

## **Compatible with:**

### **Supports iPad**

iPad Pro 11 in-ch (1st 2nd 3rd generation)  
A1980/A2013/A1934/A1979/A2228/A2068/A2230/A2231  
A2377/A2459/A2301/A2460  
iPad Pro 12.9 in-ch ( 3st 4th 5th generation  
A2378/A2461/A2379/A2462/A2229/A2069/A2232/A2233  
A1876/A2014 /A1895/A1983  
iPad Air(4th 5th generation  
A2316/A2325/A2588/A2589/A2324/A2072/A2591  
iPad mini(6th generation)  
A2567/A2568/A2569

# POM PALM REJECTION and TILT SENSITIVITY TIP

Used on iPad 2018-2023



## Conductive silicone

For Apple phones/tablets



M  
L E V E L O

🌐 www.levelobrand.com  
⌚ Levelobrand

Made in China



N  
L E V E L 0



سکای رایت

قلم ستایلس فیرسا

MODEL : LVSTPNBK - LVSTPNWH

# قلم ستايلس


استبدل الطرف



يرتبط بشكل مغناطيسي بجهاز iPad Pro لتشغيله وشحنه وتخزينه


الرجاء الاحتفاظ باتصال البلوتوث عند استخدام قلم ستايلوس. وإلا قلم ستايلوس سيغلق تلقائياً

عندما لا يمكن تشغيل قلم ستايلوس عن طريق جهاز آيپاد الخاص بك، استخدم هذه الوسادة الشحن لتشغيله.



وسادة الشحن اللاسلكي

عند لمس القلم بيدهك، سيتم تشغيله.  
عندما يغادر القلم يدك، سيتم إيقاف تشغيله تلقائياً بعد حوالي 2 دقيقة.



يمكن للموضع الذي تلمسه بيدهك تشغيل الجهاز على الفور.

166mm x8.9mm* 8.5mm	الحجم الفعلي
15.5g+2g	الوزن
5mm	حجم الطرف
Li-polymer battery	نوع البطارية
70mAh	سعة البطارية
10 hours ≈	وقت العمل
90min≈	وقت الشحن
-10°C ~ + 35°C	الشخص

- قد يختلف وقت العمل الفعلي حسب سيناريوهات الاستخدام و عوامل أخرى.

## معلومات السلامة:

- يرجى تجنب المطر أو الرطوبة عن الأجهزة والملحقات، وإلا قد يتسبب ذلك في حدوث خطر الحرائق أو التعرض لصدمة كهربائية.
- يرجى عدم وضع الأجهزة والملحقات في مناطق درجات الحرارة المرتفعة أو المنخفضة جداً، وإلا قد يتسبب ذلك في فشل الأجهزة، الحرائق، أو الانفجار. عندما تكون درجة الحرارة المحيطة مرتفعة أو منخفضة جداً، قد يتسبب ذلك في فشل الأجهزة.
- لا تفكك البطارية، ولا تصدتها، ولا تضغط عليها، ولا تعدلها. منعاً باتاً ادخال الأجسام الغريبة وثقب البطارية. منعاً باتاً أيضاً غمر البطارية بالماء أو أي سوائل أخرى لتجنب حدوث اختصار كهربائي وارتفاع درجة الحرارة وتسرب وحريق أو انفجار داخل البطارية.
- لا تفكك الجهاز أو تعدله (بما في ذلك استبدال البطارية المدمجة) ولا تقوم بتعديل الملحقات بدون إذن، وإنما في الجهاز والملحقات لن تكون مسؤولة بضمان الشركة. يرجى التواصل مع مركز خدمة العملاء إذا حدث خلل في الجهاز.
- لا تسمح بابتلاع البطارية من قبل الأطفال أو الحيوانات الأليفة لتجنب الإصابة أو انفجار البطارية.
- لا تستخدم المواد الكيميائية القوية أو وكلاء التنظيف القوية أو المنظفات القوية لتنظيف الجهاز أو الملحقات. يرجى استخدام قطعة قماش ناعمة نظيفة وجافة لمسح الجهاز أو ملحقاته.

## تعليمات العبوة:

- القلم الذكي \*
- طرف الاستبدال \*
- رمز الاستجابة السريعة للمنتج
- كبل الشحن

## حماية البيئة:

- لا تخلص من هذا الجهاز وملحقاته كنفايات منزلية.
- يرجى الامتثال لقواعد وأدلة المحافظة على البيئة للتخلص من هذا الجهاز وملحقاته، ودعم عمليات إعادة التدوير.
- البطارية تتوافق مع متطلبات حماية البيئة لتوجيه الاتحاد الأوروبي RoHS.

## أكثر حول:

هذا الدليل هو للإشارة فقط ولا يشكل أي شكل من أشكال الالتزام، المنتجات (بما في ذلك ولكن لا يقتصر على اللون والحجم وعرض الشاشة وما إلى ذلك). يرجى الرجوع إلى المنتج الفعلي. إذا كان هناك أي تضارب بين هذا الدليل والوصف على الموقع الرسمي، يرجى الرجوع إلى الوصف على الموقع الرسمي. دون إشعار.

## متوافق مع:

يعدم الآيياد.

تدعم الآيياد برو 11 إنش (الجيل الأول والثاني والثالث) النماذج التالية:  
A2231 / A2230 / A2068 / A2228 / A1979 / A1934 / A2013 / A1980

A2460 / A2301 / A2459 / A2377

وتدعم الآيياد برو 12.9 إنش (الجيل الثالث والرابع والخامس) النماذج التالية:  
A2233 / A2232 / A2069 / A2229 / A2462 / A2379 / A2461 / A2378

A1983 / A1895 / A2014 / A1876

وتدعم آيياد إير (الجيل الرابع والخامس) النماذج التالية:

A2591 / A2072 / A2324 / A2589 / A2325 / A2316

وتدعم آيياد ميني (الجيل السادس) النماذج التالية:

A2569 / A2568 / A2567


**رفض الكف وحساسية القلم بالميل.**

مستخدم على آيپاد من عام 2018 إلى عام 2023



**السيليكون قادر على التوصيل الكهربائي.**

أجهزة الهواتف والكمبيوتر اللوحي من Apple.



M  
L E V E L O

🌐 www.levelobrand.com  
⌚ Levelobrand

Made in China

