



# Power Bank 20000mAh



User Manual

## Product Diagram



## Product Parameter

Model: PPBCHA28	Material: Fireproof ABS+PC
Capacity: 20000mah @3.7V 74Wh	USB-A Output: DC 5V/4.5A,9V/2A,12V/1.5A 22.5W Max
Type-C Input: DC 5V -12V PD 18W Max	Size: 143.5 x 70 x 29mm
Type-C Output: DC 5V-12V PD 20W Max	N.W.: 390g

## Scope of Application And Recharging methods

1. Product usage: Through the USB cable and proper connectors, you can charge various digital devices with the power bank.



Smart Phone



Digital Camera






MP3/MP4



Handheld Game Console

2. Power supplement: When the product is low of battery, connect a charging cable to the USB port on a computer, AC adapter or car charger to charge the product.



## Instructions for use:

### Power indication

Power LED indicator	Bright one	Bright two	Bright three	Bright four
Mobile power supply	<25%	<50%	<75%	<100%

## Hazardous substances or elements attached to the table

Name of the parts	The name and content of hazardous substances or elements in the product					
	PB	HG	Cd	Cr6+	PBBs	PBDEs
PCB assembly	X	o	o	o	o	o
Cells	o	o	o	o	o	o
Plastic housing	o	o	o	o	o	o
Cable	o	o	o	o	o	o
Others	o	o	o	o	o	o

O: Indicating that the toxic and hazardous substances in the parts of all homogeneous materials in the SJ /T11363-2006 standard requirements below the limit requirements.

X: Indicating that the toxic and hazardous substances at least in the parts of a homogeneous material content exceeds the sj / T11363-2006 standard limit requirements.

Note 1: Most of the components of this product are made of non-toxic and harmless environmentally friendly materials. Parts containing toxic and hazardous substances or elements are not subject to the limitations of global development and can not replace toxic and hazardous substances or elements.

Note 2: The reference standard for the environmental protection period depends on the conditions such as the temperature and humidity for the normal operation of the product.(Environmental Protection Use Period)

## WARNING

- The power bank is NOT a toy and should be kept away from children.
- Please do NOT use the power bank in direct sunlight or extreme heat for extended periods of time.
- Please do NOT submerge the power bank in water.
- Please do NOT leave the power bank near the fire.
- Please do NOT subject the power bank to harsh chemicals.
- Please do NOT use the power bank if it has been damaged and/or modified.
- Please do NOT insert any foreign objects into the openings or port of the power bank.
- Please do NOT attempt to disassemble, repair, or open the power bank in any way.